

System 8000

Steeplechase water jump kit









System 8000 Steeplechase water jump

Description	Part No.	Overall Depth		Weight
		inches	mm	lbs.
Water jump construction kit Comprises: 14 straight sections (525mm) (A) 2 corner pieces (B) 4 straight sections (600mm) (C) 38 interlocking bars 76 hex head bolts 76 washers	02159	29.36	753	2,480.0

Part I - General

- 1.1 Related Work Work specified in other sections includes but is not limited to: Excavation and backfill, cast-in-place concrete, and mechanical equipment.
- 1.2 System Description elastic edged water jump pre-cast from corrosion resistant polyester polymer concrete for on-site installation.
- 1.3 Submittals Manufacturer will submit, when required, shop drawings showing schematic plan of water jump system listing all parts being provided with exact center-line dimensions suitable for installation. Copies of the manufacturer's recommended method of installation, assembly, and anchorage shall be submitted for review.
- 1.4 Project History Manufacturer shall submit a list of projects installed during the past twenty years, if required.
- 1.5 Warranty ACO provides a limited warranty of one year based on installation according to manufacturer's installation instruction data.

Part II - Product

2.1 **Products** - Manufacturer shall be ACO Polymer Products, Inc.

2.2 Physical & Mechanical Characteristics

- Internal width 12' (3.65m)
- Internal length 11'- 9.5" (3.95m)
- Compressive strength 14,000 psi
- Flexural strength 4,000 psi
- Water absorption rate < 0.1% by weight.
- 2.3 Water Jump Profile Shall include an integrally cast EPDM rubber safety edge. Pre-cast polymer concrete units shall have 14 sections at lengths of 20.66" (525mm), 4 sections at 23.62" (600mm) and 2 corner sections of 11.75" (298mm).

Part III - Installation

- 3.1 Site Preparation Excavate area for water jump placement wide enough and deep enough to accommodate water jump and 8-10 inches (200-250mm) concrete encasement. Units require 8-10 inches (200-250mm) of concrete support on both sides as well as beneath units. A string line or laser should be used to set water jump at the required level.
- 3.2 Installation Water jump sections are installed end to end to create the walls of the water jump. Each section shall be placed on brick or low slump concrete grout slurry to obtain correct finished elevation. Cover EPDM safety edge with tape or plastic to protect the surface during concrete pour. Base should be constructed by contractor in materials and grade specified.
- 3.3 Finishing and Clean-up Following final set of concrete, remove protection covering the top of each water jump section.
- 3.4 Install in strict accordance with manufacturer's recommendations and drawings. Details available at www. acousa.com/install_drawings_sport.htm

ACO Polymer Products, Inc.

East Sales Office P.O. Box 245 Chardon, OH 44024

Chardon, OH 44024 Tel: (440) 285-7000 Toll free: (800) 543-4764 Fax: (440) 285-7005 **West Sales Office**

P.O. Box 12067 Casa Grande, AZ 85230 Tel: (520) 421-9988 Toll Free: (888) 490-9552 Fax: (520) 421-9899

Electronic Contact: info@acousa.com www.acousa.com

